




MC-NOVA2

EN User manual / ES Manual de usuario / PT Manual do usuário / FR
Manuel de l'utilisateur / IT Manuale d'uso / DE Benutzerhandbuch /
PL Instrukcja obsługi / NL Gebruikershandleiding / دليل الاستخدام

I / O PANEL




I/O PANEL




ACCESSORIES

Accesorios / Acessórios / Accessori /
Accessoires / Zubehör / Akcesoria / Accessoires / مُكَمَّلَات




2.5" SSD & 3.5" HDD




POWER SUPPLY INSTALLATION

Instalación de fuente de alimentación / Instalação de fonte de
alimentação / Installazione dell'alimentatore / Installation de
l'alimentation / Stromversorgung Installation / Instalacja
zasilania / Voeding installatie / تركيب مصدر الطاقة




MOTHERBOARD INSTALLATION

Instalación de la placa base / Instalação da placa-mãe /
Installazione della scheda madre / Installation de la carte
mère / Installation des Motherboards / Instalacja płyty
głównej / Moederbord installatie / تركيب اللوحة الأم



GRAPHIC CARD INSTALLATION

Instalación de la tarjeta gráfica / Instalação da placa gráfica /
Installazione della scheda grafica / Installation de la carte graphique
/ Installation der Grafikkarte / Instalacja karty graficznej / Grafische kaart
installatie / تركيب بطاقة الرسومات



EN

Security Reminders

- Do not use the product in areas with high humidity or near water.
- Keep children away from the parts while installing the product.
- Protect your hands and fingers when handling and installing the parts.
- Place the product on a flat surface.
- Ensure all components and panels are installed correctly and screws are tightened.
- Unplug the equipment from the power outlet before cleaning the chassis.
- Use a soft, dry cloth to clean the table. Do not use abrasive cleaners or solvents.
- Keep the equipment in a clean and dry environment, as dust and humidity can limit the lifespan of computer components.

Troubleshooting

Computer does not power ON: Refer to the motherboard documentation and ensure the POWER button is connected in the correct location on the motherboard.

Front panel connectors not working: Verify that the front panel connectors (USB, HD AUDIO) are properly connected to the corresponding connectors on the motherboard. Ensure motherboard drivers are up to date and correctly installed. Test the functionality of USB and Audio connectors with different devices to determine if the issue persists.

Component compatibility: Refer to the product specifications sheet at www.marsgaming.eu for detailed information on case compatibility with graphics cards, liquid cooling, air coolers, and fans. If further assistance is needed, do not hesitate to contact us for support. Please note that the vertical CPU adapter and VGA riser are not included with the product.

Warranty

The original purchase receipt will be required to use the warranty service. Keep it in a safe place. Product manipulations, technical modifications of any kind, and damages due to external mechanical forces will void your warranty. To read the terms and conditions of the warranty, visit es.marsgaming.eu/es/terms

Compliance

You can consult the European Union Declaration of Conformity of the product at www.marsgaming.eu/en/conformity. For more information, visit www.marsgaming.eu

Disposal and Recycling

At the end of the product's life, it should not be disposed of with regular household waste. To promote environmental sustainability and ensure proper waste management, take the product to a designated collection and recycling center.

Contact

If you have questions or need spare parts for the product, do not hesitate to contact us: attclntce@biomag.es / +34945124598

ES

Recordatorios de Seguridad

- No utilice el producto en áreas con alta humedad o cerca del agua.
- Mantenga a los niños alejados de las piezas mientras instala el producto.
- Proteja sus manos y dedos al manipular e instalar las piezas.
- Coloque el producto sobre una superficie plana.
- Asegúrese de que todos los componentes y paneles estén instalados correctamente y los tornillos estén apretados.
- Desenchufe el equipo de la toma de corriente antes de limpiar el chassis.
- Use un paño suave y seco para limpiar la mesa. No use limpiadores abrasivos o disolventes.
- Mantenga el equipo en un ambiente limpio y seco, el polvo y la humedad pueden limitar la vida útil de los componentes de la computadora.

Resolución de Problemas

El equipo no se enciende: Consulte la hoja de especificaciones del producto y compruebe que el botón POWER (PWR) de encendido está conectado en el lugar correcto de la placa base. Los conectores del panel frontal no funcionan: Verifique que los conectores del panel frontal (USB, AUDIO HD) estén conectados correctamente a los conectores correspondientes en la placa base. Asegúrese de que los controladores de la placa base estén actualizados y correctamente instalados. Pruebe la funcionalidad de los conectores USB y de Audio con diferentes dispositivos para determinar si el problema persiste.

Compatibilidad de componentes: Consulte la hoja de especificaciones del producto en www.marsgaming.eu para obtener información detallada sobre la compatibilidad de la caja: tarjeta gráfica, refrigeración líquida, disipadores de aire y ventiladores. Si necesita más ayuda, no dude en ponerse en contacto con nosotros para obtener soporte. Tenga en cuenta que el adaptador de tarjeta gráfica vertical y el VGA riser no están incluidos con el producto.

Garantía

Se requerirá el recibo de compra original para utilizar el servicio de garantía. Manténgalo en un lugar seguro. Las manipulaciones del producto, las modificaciones técnicas de cualquier tipo y los daños debido a fuerzas mecánicas externas anularán su garantía. Para leer los términos y condiciones de la garantía, visite es.marsgaming.eu/es/terms

Cumplimiento

Puede consultar la Declaración de Conformidad de la Unión Europea del producto en www.marsgaming.eu/en/conformity. Para obtener más información, visite www.marsgaming.eu

