



# MCPUX CPU COOLER



WWW.MARSGAMING.EU


## PRODUCT OVERVIEW

- |                 |                    |
|-----------------|--------------------|
| 1 Back Plate    | 4 AMD Bracket      |
| 2 Bracket Screw | 5 Thermal Grease   |
| 3 Intel Bracket | 6 LGA 2011 Bracket |




## INTEL INSTALLATION

**STEP 1:** Please remove the fan before installing radiator by opening the buckles pointed by the arrow.




## INTEL INSTALLATION

**STEP 2:** Install the bracket mount on the cooler base and fasten the screws.




## INTEL INSTALLATION

**STEP 3:** Evenly spread the heatsink paste on the surface of the CPU and remove the plastic protection.




## INTEL INSTALLATION

**STEP 4:** Move the bracket screw to the corresponding position according to the motherboard socket type.




## INTEL INSTALLATION

**STEP 5:** Move the backplate slider to the corresponding motherboard socket LGA115X/17XX/1366, if the motherboard socket is LGA2011 use the original motherboard backplate.




## INTEL INSTALLATION

**STEP 6:** Place the radiator on the CPU and screw the backplate to the bracket mount.



## INTEL INSTALLATION

**STEP 7:** After installing the fan, connect the PWM cable to the CPU-FAN connector of the motherboard.



EN  
Do not attempt to repair the product yourself, removing the covers will void the warranty. At the end of the product life please dispose this product at your local waste collection/recycling centre.

ES  
No intente reparar el producto usted mismo, quitar las cubiertas anulará la garantía. Al final de la vida útil del producto, deséchelo en su centro local de recogida/reciclaje de residuos.

PT  
Não tente reparar o produto você mesmo, a remoção das coberturas anulará a garantia. No final da vida útil do produto, por favor, elimine este produto no seu centro local de recolha/reciclagem de resíduos.

FR  
N'essayez pas de réparer le produit vous-même, le retrait des couvercles annule la garantie. A la fin de la vie du produit, veuillez vous débarrasser de ce produit dans votre centre local de collecte/recyclage des déchets.

IT  
Non tentare di riparare il prodotto da soli, la rimozione delle coperture annullerà la garanzia. Alla fine della vita del prodotto, si prega di smaltire questo prodotto presso il centro di raccolta/riciclaggio dei rifiuti locale.

DE  
Versuchen Sie nicht, das Produkt selbst zu reparieren; durch Entfernen der Abdeckungen erlischt die Garantie. Entsorgen Sie das Produkt am Ende seiner Lebensdauer bei Ihrer örtlichen Müllabfuhr.


PL  
Nie próbuj samodzielnie naprawiać produktu, zdjęcie osłon spowoduje utratę gwarancji. Po zakończeniu okresu eksploatacji produktu należy go zutylizować w lokalnym punkcie zbiórki/recyklingu odpadów.

RU  
Не пытайтесь ремонтировать изделие самостоятельно, снятие крышек приведет к аннулированию гарантии. По окончании срока службы продукта утилизируйте его в местном центре по сбору / переработке отходов.

Declaration of conformity / Declaración de conformidad /  
Déclaration de conformité / Dichiarazione di conformità /  
Declaração de conformidade / Konformitätserklärung www.mars-gaming.eu/en/conformity


AMD INSTALLATION

STEP 1: Please remove the fan before installing radiator by opening the buckles pointed by the arrow.




AMD INSTALLATION

STEP 2: Install the AMD bracket mount on the cooler base and fasten the screws.




AMD INSTALLATION

STEP 3: Remove the upper bracket on the AMD motherboard.




AMD INSTALLATION

STEP 4: Evenly spread the heatsink paste on the surface of the CPU and remove the plastic protection.




AMD INSTALLATION

STEP 5: Move the screw on the bracket to the corresponding position according to the motherboard socket type.




AMD INSTALLATION

STEP 6: Place the radiator on the CPU and screw the backplate to the bracket mount.



AMD INSTALLATION

STEP 7: After installing the fan, connect the PWM cable to the CPU-FAN connector of the motherboard.




ARGB CONTROL LIGHTING

Connect the ARGB +5V 3pin connector to the ARGB motherboard / controller connector. Compatible with: Asus Aura Sync, Mystic Light Sync, RGB Fusion (Aorus) and ARGB controllers

Note to user: Check for ARGB compatibilities on your motherboard's user manual. Please keep this sheet for future reference. Visit our website [www.marsgaming.eu](http://www.marsgaming.eu) for more info about your product.

ARGB CONTROL LIGHTING




From Mars Gaming team:  
we want to thank you for the purchase of this product!  
We try to improve everyday to offer the best service and the best quality on our peripherals. Thank you for your trust!

ARE YOU HAPPY WITH YOUR PURCHASE?



Rate us in your marketplace and share your experience in your social media



Please contact our technical support service by sending an e-mail to

